Changing the battery/Removing the Snap Ring

15. To remove the snap ring to change the sensor battery, use a screwdriver or similar.
16. Insert screwdriver into the slot on the snap ring, and pry snap ring tab outward to unlatch it from the retaining ring.
17.
18. Repeat for each of the tabs until snap ring comes off.
19. Sensor can now be removed to change the battery.

